

Using Lagged Spectral Data in Feedback Control Using Particle Swarm Optimisation

Mr. Caleb Rascon Prof. Barry Lennox Dr. Ognjen Marjanovic



Using Spectral Data in Monitoring

- Pharmaceutical Industry
 - Crystallisation of active ingredients (Yu et. al., 2003)
 - Confirm sample temperature
 - Identify material concentrations
- Viable as observed variables in feedback control
 - Or are they?



Difficulties of Using Spectral Measurements

- Known for inconsistency due to:
 - Instrument de-calibration
 - External and/or sample temperature
 - Presence of undesired material
- Results in frequency displacement (aka, shift, lag)
- Disastrous if using reference spectra for analysis




Classical Least Square Regression

$$C = DS(S^TS)^{-1}$$


- D: a spectral measurement
- S: set of reference spectra
- C: set of concentrations
- S and C need to be aligned



Example: Components




Combining the strengths of UMIST and The Victoria University of Manchester






Response using CLSR wo. Applying Lag



Combining the strengths of UMIST and The Victoria University of Manchester



Response using CLSR Applying Lag



The Victoria University of Manchester



Approach as a Search Problem

- Find combination of reference spectra that best fits sample
- For each reference spectrum, look for:
 - Magnitudes \rightarrow concentrations
 - Shift suffered
 - [Others can be added...]
- Use Euclidian distance to grade the combination




The University of Mancheste

Particle Swarm Optimisation

- Created by Kennedy in 1995
- Simulates a flock of birds 'flying' in the solution space
- Proven to do as well or better than Genetic Algorithms (Kennedy et. al., 1995)
- Easier to implement and visualise
- Can incorporate the concept of inertia to speed up search



Response using PSO Applying Lag



Combining the strengths of UMIST and The Victoria University of Manchester

Comparison

Mean Square Error of responses using CLSR and PSO				
Component	1	2	3	4
MSE w. CLSR	0.9639	1.0171	0.6966	1.6604
MSE w. PSO	0.0339	0.0319	0.0375	0.0373

The baseline of comparison is the response obtained when no lag was applied.

MANCHESTER 1824

Conclusions & Future Work

- Classical spectral analysis methods are frail towards lag
- As a search problem, lag can be factored in
 - Other disturbances too
- Useful in monitoring:
 - Inform the need for sensor calibration
 - Alternative temperature measurements
- Search per sample: ~ 6 min
 - Future work: shortening time of completion